



**Proofs:** **Emailed Electronic PDF Proofs,** add 2 working days to the item production. First proof is free of charge. Additional proofs available for an additional charge. Production time begins after receipt of complete order including proof approval.

**Production Samples,** physical product proofs are available using customer artwork. These are offered at a % off the one quantity price. Standard production times will apply.

**Complimentary Proof** may be required for certain orders to ensure satisfaction. Production time will be begin upon approval of the proof.

**Product Weight:** **NOTE:** weight shown is for (1)

| Description                    | Overall Size<br>H" x W" x D" | Product Weight<br>lbs.<br><small>**includes stamp + ribbon + placement tool ruler</small> |
|--------------------------------|------------------------------|---|
| Self-Inking Mine® Fabric Stamp | 2¾" H x 2¼" W x 1⅞" D        | 0.10  |

**Packaging:** Box shipping container.  
Multiple stamps will ship in one shipping container, multiple containers pending quantity.

**Changes or Cancellations:** Changes to orders in progress may require additional charges and/or time. Cancellations for orders in progress will require payment for the order.

**Application/Care Instructions:** See page 3



## TEXTILE MARKER INSTRUCTIONS



Instruction sheet for placement tool ruler and white ribbon transfer tape will be sent with each stamp.

### Using Placement Tool

(For Imprint without Ribbon)

Instructions for using placement tool to make sure your impression is in just the right spot.



Align placement tool so that the window is centered in desired location for stamp imprint.



Position Mine® Stamp within window of the placement tool.



Press down on Mine® Stamp to make imprint.

### Using Iron-On Ribbon

Instructions for using iron-on ribbon for marking on dark clothes.



Feed ribbon through guide slots and window of positioning tool as shown.



Position Mine® Stamp within window of the placement tool on top of ribbon and press down on Mine® Stamp to make imprint.



Once imprint is made, remove ribbon from positioning tool and cut down to size.



Place ribbon on fabric and apply hot iron (Cotton Setting) to fuse ribbon to fabric.



Note: Always consider care recommendations for fabrics. Do not apply to fabric that will be damaged by heat of iron.