



TEXTILE MARKER INSTRUCTIONS



Instruction sheet for placement tool ruler and white ribbon transfer tape will be sent with each stamp.

Using Placement Tool

(For Imprint without Ribbon)

Instructions for using placement tool to make sure your impression is in just the right spot.



Align placement tool so that the window is centered in desired location for stamp imprint.



Position Mine® Stamp within window of the placement tool.



Press down on Mine® Stamp to make imprint.

Using Iron-On Ribbon

Instructions for using iron-on ribbon for marking on dark clothes.



Feed ribbon through guide slots and window of positioning tool as shown.



Position Mine® Stamp within window of the placement tool on top of ribbon and press down on Mine® Stamp to make imprint.



Once imprint is made, remove ribbon from positioning tool and cut down to size.



Place ribbon on fabric and apply hot iron (Cotton Setting) to fuse ribbon to fabric.



Note: Always consider care recommendations for fabrics. Do not apply to fabric that will be damaged by heat of iron.